


Concept & background

Robust Aged Feature set for Visual Odometry

*ISL Lab Seminar
Jin Hyung Kim
2015.05.15.*


Contents



Introduction : Visual Odometry

● Visual Odometry

- The process of estimating the **egomotion** of an agent using **only the input of** a single or multiple **cameras** attached to it
- The term VO was coined in 2004 by Nister in his paper*
 - Was chosen for its similarity to wheel odometry




*D. Nister, O. Naroditsky, and J. Bergen, "Visual odometry," in *Proc. Int. Conf. CVPR*, 2004, pp.652-659.

Visual Odometry


- **Advantages of VO**

- Is not affected by **wheel slip** in **uneven terrain** or other adverse conditions
- Provides **accurate** trajectory estimates
- **Additional** near space **information** acquisition
 - IMU, GPS, Wheel Odometry : egomotion only
- **Low cost** comparing to IMU, Laser Odometry
- **Capable in GPS-denied environments**
 - Underwater, Aerial, indoor, another planet

Positive condition for VO




Sufficient illumination




Static scene with enough textured features


Consecutive frames
that have sufficient scene overlap




VO Pipeline (2D to 2D)



Tradeoff : baseline & correspondence




Camera movement




Feature Tracking

Short baseline : low ME accuracy
Guaranteed feature correspondence



Feature Matching

long baseline : High ME accuracy
Poor feature correspondence
(even heavy computation for descriptor)




Match after track

long baseline : High ME accuracy
Guaranteed feature correspondence

Limit of “Match after Track”

- Feature blinking problem : decreasing number of feature



Robust Aged Feature set

- **How to obtain accurate Essential matrix.**

- Sufficient reliable correspondences
 - Repeatable & Traceable feature extraction(Aging & tracking)
 - Adding feature of new part of scene(Feature detection & matching)
 - Outlier rejection
- Sufficient long baseline length
 - Sufficient pixel movement


- **VO : Real-time**

- Low-complex feature detector
- Low-computational descriptor
- Simple tracking algorithm

**Increase the number of features as many as possible &
Select the reliable features and keep traceable...**

Robust Aged Feature set


- Structure of RAF




- RAF set

- List formation

➤ to erase & add frequently




VO Procedure using RAFset



Outlier Filter for Optical Flow output

- Correspondence outlier



Caused by
Noise, blinking feature, moving object, etc.

- Outlier filtering

$$e_i = \sqrt{(x_i - x'_i)^2 + (y_i - y'_i)^2}$$

$$\bar{e} = \sum_{i=0}^n e_i, \quad \sigma_e = \sqrt{\sum_{i=0}^n e_i^2 - \bar{e}^2}$$


$$T_{outlier} = \bar{e} + \sigma_e$$

where, $(x, y) \xleftrightarrow{\text{correspondence}} (x', y')$

Inliers should be smaller than $T_{outlier}$

Overlap check

In order to reduce computation, check **overlapped** features.
(Near distance)




Aging Strategy




De-aging

- Disappeared
 $[1/n]$



Aging

- Tracked
- Overlapped
- Reappeared



Stop state detection

- **Even static situation, Motion vector occurs in image**

- Vibration of camera mount
- Scattering noise
- Illumination blinking


- **Using average amplitude of Motion vectors**

$$e_i = \sqrt{(x_i - x'_i)^2 + (y_i - y'_i)^2}$$

where, $(x, y) \xleftrightarrow{\text{correspondence}} (x', y')$

$$\bar{e} = \sum_{i=0}^n e_i$$


if $\bar{e} < T_m$, then the cam is stopped



Sufficient pixel movement detection

- **Also, using Accumulated Average amplitude of MVs**

- However, amplitude of MV is scalar.
 - Recognizes periodic movement to large movement



- Therefore it is required to use displacement btw. Initial frame to current frame
- In order to reduce computation load,
 - Calculates displacement when sufficient amplitude of MV accumulated.
 - Not per frame

Future work

- **Descriptor management**
- **Scale problem**
- **Visualization**
- **Experiment**