Oct 24, 2016

Active stereo vision system for object position estimation

Lab Seminar

Han Sol Kang

Contents

Introduction

Active Stereo Vision

Progress of the Project

- Color Code
- Periodic Color Code
- Experimental Results


Conclusion

Introduction

Conventional Stereo Vision

Conventional Stereo Vision

: Stereo vision is the extraction of 3D information from digital images, such as obtained by a CCD camera. **By comparing information about a scene from two vantage points**, 3D information can be extracted by examination of the relative positions of objects in the two panels. This is similar to the biological process **stereopsis**.








Introduction

Active Stereo Vision

Active Stereo Vision

: The active stereo vision is a form of stereo vision which actively employs a light such as a laser or a structured light to simplify the stereo matching problem.




Color Code

Debruijn sequence

Alphabet: {0, 1} Subsequence length: 2

Subsequences:



$$2^2 = 4$$



Color Code


Debruijn sequence

n=3, k=3 (alphabet is $\{0, 1, 2\}$) $3^3 = 27$

000111222012022110021210102

n=3, k=3 (alphabet is $\{b, g, r\}$)

bbbgggrrrbgrbrrggbbrgrgbgbr



Color Code


Debruijn sequence – Occlusion problem





Color Code

Debruijn sequence – Occlusion problem



000, 001, 010, 011, 100, 101, 110, 111


000, 001, 011, 110, 101, 010, 100

We obtain wrong codes


Periodic Color Code

Periodic Color Code

Stereo matching using line scanning




Stereo matching using periodic color code



matching using coded pattern

Periodic Color Code


Flow Chart




*PCC: Periodic Color Code

Periodic Color Code

Processing ROI






ROI image

Periodic Color Code

Processing ROI




Original Image



Projection Image







Processing ROI

Periodic Color Code


Disparity ROI






Periodic Color Code

Problem of prior threshold






We can obtain a good result using adaptive threshold

Periodic Color Code


Adaptive Threshold Flow Chart



n(HG): the number of high groups n(LG): the number of low groups

Periodic Color Code

Adaptive Threshold Example




Threshold value: use a nearby threshold value

220	230	240	240	230
220	230	240	240	230
220	230	240	240	230
220	230	240	240	230
220	230	240	240	230

mean: 232

high group mean: 240 low group mean: 226.67

threshold value: -1



Threshold value: use a mean value

20	50	240	240	50
20	50	240	240	50
20	50	240	240	50
20	50	240	240	50
20	50	240	240	50


mean: 120

high group mean: 240 low group mean: 40


threshold value: 120

Periodic Color Code


Adaptive Threshold Result



Input Image




Prior threshold method



Adaptive threshold method


Periodic Color Code

Decoding



Periodic Color Code

Decoding - HSV Threshold



$$H = \begin{cases} H1 & \text{if } B \le G \\ 360^{\circ} - H1 & \text{if } B > G \end{cases}$$

$$H = \begin{cases} H1 & \text{if } B \le G \\ 360^{\circ} - H1 & \text{if } B > G \end{cases} \qquad H1 = \cos^{-1} \left\{ \frac{0.5[(R - G) + (R - B)]}{\sqrt{(R - G)^{2} + (R - B)(G - B)}} \right\}$$

$$S = \frac{Max(R,G,B) - Min(R,G,B)}{Max(R,G,B)}$$

$$V = \frac{Max(R, G, B)}{255}$$

Use hue and saturation value


example

H(i,j) < Hth1 & H(i,j) > = Hth2 & S(i,j) > Sth


H(i,j): hue value at i, j S(i,j): saturation value at i, j

Periodic Color Code

Decoding result




before unwrapping




after unwrapping

Experimental Results

PCC method






distance btw camera and object: 250mm

base line: 30mm

Experimental Results

PCC method – residual error filtering




distance btw camera and object: 250mm

base line: 30mm

Experimental Results

Line scan method



distance btw camera and object: 250mm

base line: 30mm

Conclusion

Perform the PCC method

- Use the adaptive threshold for finding disparity ROI
- Use the residual error filtering to reduce the error
- PCC of error is about 0.0568949 mm (f to b and b to f)

